

IX.3.3C-SYSTEM-MOD102 COMMON BLOCK MOD102

Purpose

Common block MOD102 contains the variable portion of the baseflow values obtained from the BASEF MOD [[Hyperlink](#)] or BFRATE MOD [[Hyperlink](#)] to replace the baseflow in the current BASEFLOW Operation [[Hyperlink](#)].

Only values that fall within the current run period are stored.

This common block is filled only for BASEFLOW Operations that have the variable baseflow recession enabled.

Listing

```
COMMON /MOD102/ NDT02, IDT02(5), VAL02(5)
```

Description of Variables

<u>Variable</u>	<u>Type</u>	<u>Dimension</u>	<u>Word Position</u>	<u>Description</u>
NDT02	I*4	1	1	Number of variable baseflow values and dates entered through BASEF or BFRATE MODs for the current BASEFLOW Operation
IDT02	I*4	5	2	Julian hours in chronological order for the variable baseflow values in array VAL02
VAL02	R*4	5	7	Variable baseflow values to be applied at the dates stored in array IDT02 (units of CMS)